


COREOPLAY™ COLLECTION



VORTEX

CoreoPlay™ collection

Version 2 December 2023

© Vortex Aquatic Structures International, 2023

This document may not be reproduced, copied or used for other purposes than stipulated without the prior written authorization of Vortex Aquatic Structures International Inc. The information herein may be modified without notice.


Vortex Aquatic Structures International Inc. has manufactured or assembled all structures and components described in this manual.

All plans, drawings, documents and text herein are the property of Vortex in perpetuity, and may not be reproduced, in whole or in part, without the prior written authorization of Vortex Aquatic Structures International Inc.

ALL RIGHTS RESERVED.


TABLE OF CONTENTS

FAMILY OVERVIEW




PAGE 4

PARTS OVERVIEW



PAGE 5

PRODUCT INSTALLATION




PAGES 6-7

ELECTRIC CONNECTION




PAGE 8

NOZZLE




PAGE 9

RECOMMENDED HEIGHT



PAGE 9


WINTERIZATION




PAGE 10

COREOPLAY™ COLLECTION


FAMILY OVERVIEW




VOR 7060 - COREOPLAY™ SUNSET




VOR 7063 - COREOPLAY™ VOLCANO




VOR 7062 - COREOPLAY™ OCEAN



VOR 7065 - COREOPLAY™ WAVE



VOR 7061 - COREOPLAY™ RAINBOW



VOR 7064 - COREOPLAY™ FIREWORK




! REQUIREMENTS : MAESTROPro™, LUMIFLOW POWER PACK AND VALVE TYPE, SOLD SEPARATELY

LUMIFLOW

! VERY IMPORTANT TO SEE THE PIPING AND CONNECTION DIAGRAM FOR LED POSITIONING TO COMPLY WITH THE PROGRAMMING.






PARTS OVERVIEW




! SEE THE INSTALLATION DRAWINGS AND/OR THE PIPING AND CONNECTION DIAGRAM

COREOPLAY™ COLLECTION - LUMIFLOW INSTALLATION


 SEE THE INSTALLATION DRAWINGS AND THE PIPING AND CONNECTION DIAGRAM FOR MORE INFORMATION.





NOTE : Run the wiring from the electrical pipe, leaving a 24 inch (60 cm) length in the canister for eventual connections.

7




Make sure that the watertight part is present to make the water line watertight.

Perform the pressure test with the plastic winter cap on ; keep the cap on during concrete placement.


NOTE : Remove the watertight part after the pressure test to release the water.

PRESSURE TEST


8



PIPING AND CONNECTION DIAGRAM



POSITIONING




NOTE : Match each LED with its niche for positioning on the SplashPad according to its number.

! VERY IMPORTANT TO SEE THE PIPING AND CONNECTION DIAGRAM FOR LED POSITIONING TO COMPLY WITH THE PROGRAMMING.


LED & POSITIONING

9

COREOPLAY™ COLLECTION - ELECTRICAL CONNECTION




12/24 VAC PHASE	GND	DMX +
		DMX -
	12/24 VAC NEUTRE	DMX G




CONNECTION TO ELECTRICAL PANEL

COREOPLAY™ COLLECTION - NOZZLE



COREOPLAY™ COLLECTION - RECOMMENDED HEIGHT



COREOPLAY™ COLLECTION - WINTERIZATION

